

VERTEBLADE

The Verteblade Backrest for Harley Davidson solo seat fits Full Fender and Bobtail Fender Instructions:

1. Remove seat
2. Remove seat mounting bolt, located on top of the fender.
3. Install one 1/4" rubber black well nut in hole, located on top of the fender.
4. Use blue masking tape to protect the fender and temporarily place curved Verteblade base plate on the fender securing it with chrome 1/4" chamfered bolt.
5. Use sharpened pencil to mark two remaining holes, finish with a countersink punch.
6. Remove Verteblade base plate and drill holes in fender, starting with a smaller drill bit and finishing with 1/2". For best results, use a high quality step bit and finish off with a file or dremel. Rubber well nut must fit tight.
7. Pre assemble Verteblade base and vertical support using three 1/4" stainless bolts (do not over tighten).
8. Secure Verteblade base to fender, chrome bolt on top of fender, two stainless at bottom.
9. Install seat. Most solo seats will fit with no modification.
10. Secure backrest mounting plate to Verteblade vertical support using two stainless bolts.
11. Finally, secure Verteblade backrest cushion to backrest mounting plate using two chrome button head 1/4" bolts.

For any questions, please contact Lisa Peters at lisa@verteblade.com.

